

Veridian Petrochemicals  
Bharuch Complex

Document no: SOP-CDU-STARTUP-SEQUENCE Revision: B  
Title: Start-up of the crude distillation unit  
Owner: Prakash Menon  
Issued: 07 December 2025

Primary equipment: P-1101A, Crude feed pump A

Purpose. Start-up of the crude distillation unit.

Method. Confirm the heater purge, line up crude feed through P-1101A or P-1101B, establish reflux with P-1102A and bring the column to temperature at 30 degC per hour. Do not exceed the heater outlet temperature of 365 degC during heat-up. Hand over the unit to the shift lead only when the column pressure is steady at 1.4 barg.